

Line walls to new wet shower area with 'Hardiglaze' on 50x12 battens all in accordance with manufacturers installation instructions.

existing wall

Bottom batten tanalised H3

100x50 nog between studs

existing bottom plate

100x50 solid blocking to perimeter of shower

Note: seal back of sheet up a min 100mm & bottom edge with 'Dulux Primercyl'

Silicone sealant

Vinyl flooring fixed in accordance with manufacturers instructions. Chemically weld all joints & cover up wall 130mm to shower area. & 100mm to other wall areas.

H3/17.5mm construction grade plywood laid to fall 20mm to drain
Install fillets & packers as required

Trim existing floor joists to allow plywood to fall to drain

Remove existing flooring to new shower area & install construction grade plywood H3

Install new vinyl flooring to complete shower

Install 'Masonite' over existing flooring in accordance with manufacturers instructions, prior to laying vinyl.

New 100x50 blocking to perimeter of new shower & elsewhere as required. Note: screw down existing flooring to new blocking before fixing 'Masonite'.

DETAIL SHOWER to WALL

DETAIL SHOWER to FLOOR

CONSTRUCTION DETAILS for WET AREA SHOWER in EXISTING HOUSE

(1:5)

Approved

These plans/specs are approved in accordance with The N.Z. Building Code.

Ross Hamilton, Building Certifier # 21.

Date 7/12/2000

Building Certificate # 26.

New Zealand Building Certifiers Limited.

Western Bay of Plenty District Council
Building Consent issued with number

64225
Ross Hamilton Building certifier

FARRS
ARCHITECTURAL
DRAUGHTING
SERVICE
50 Emeny Rd.
RD2 Tauranga

Ph / Fax (07) 548 0601

JOB 46100

Sht 3

2/11/00